

Operating mode
Reservation Parameter Setting Mode
Split system parameter setting mode №1
Split system parameter setting mode №2
Service mode
Return to factory parameters
menu / exit
hold for 3 sec
+/->
-/<-
next / enter
back
RESET
After exiting the menu, a reboot will occur. After rebooting, the device will start working with new parameters.